

playmobil®

9315



# WARNING: CHOKING HAZARD

Small parts. Not for children under 3 years.



"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren!  
Important: Please keep these instructions for future reference!  
Documents importants, à conserver soigneusement!  
Belangrijke documenten, bewaar deze zorgvuldig!






1






2









1



2







2x










4







5







6

2x






7












1




2







10


4x



2x












1




2







1



2




3









3



4








30 23 5172




30 00 2504




30 14 0932



30 08 1532




30 46 4322




30 45 0782







30 08 1412




4x 30 21 1490




30 02 8750




30 21 1480




30 22 3640



30 22 5300




30 22 5350




2x 30 21 6190







4x 30 08 1542



2x 30 28 6200




2x 30 08 1562




4x 30 22 4143




2x 30 08 1552




30 22 4112




30 08 1432



2x 30 08 1452




2x 30 08 1462



4x 30 08 1512




4x 30 08 1502



4x 30 08 1472



30 66 8180



4x 30 05 2180






2x 30 23 7352



30 07 0520



30 08 1402



2x 30 21 1500



3x 30 08 1422




30 25 9003



30 27 8280



30 25 0973



4x 30 23 8790




30 66 4790




30 25 3892



3x 30 24 5450




30 08 1482




30 08 1492



30 51 9430




30 60 1142



30 61 0602





|                                                                                    |                                                                                                               |
|------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|
| Serviceadressen finden Sie in allen Playmobil-Prospekten                           | In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.                                          |
| Addresses of Customer Service Departments are shown in all Playmobil catalogues    | Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil |
| L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil | Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL      |
| Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil    | pronounce: plāy-mō-bēēl                                                                                       |